

VIRPIL BASE CONFIGURATION STEPS

1. Open the VIRPIL Configuraton program that you can download from the VIRPIL website
2. Select the **Thrustmaster Cougar Stick** in the VIRPIL Configuration program
3. Upload the new configuration to your base
4. The PTT and AP Disc/Prio buttons should now work normally
5. You need to recalibrate the VIRPIL base after programming it